

# How to Paint a Color Block Wall

with Purdy®

## Before you start: **Gather supplies.**

- 2" or 2.5" Clearcut® brush
- WhiteDove™ 9" x 3/8" Roller Covers
- Revolution Frame
- NEST™ 9" Tray
- NEST 9" Tray Liner
- 2-4' Power Lock® Extension Pole
- Paint in at least 2 colors
- Stir Sticks
- Tape
- Pencil and a Level

## STEP 1: Plan your design.

Wipe walls with a clean, damp cloth to prepare painting surface. Use a pencil to lightly draw the lines for your design.

» **Helpful tip: Use a level to ensure your lines are parallel with edges of the room.**

## STEP 2: Tape.

Carefully tape off the trim and the marked area. Then press your thumb over the tape edge to make sure it fully seals against the wall.

## STEP 3: Apply first color.

Using your WhiteDove roller, apply your first color working in "V" pattern. WhiteDove provides a smooth, lint-free finish.

» **Helpful tip: Use paint + primer or one-coat coverage paint formula to help you finish the project faster.**

## STEP 4: Peel the tape.

While the paint is still damp, carefully peel the tape off. Allow paint to dry.

## STEP 5: Tape off next section.

After the paint is fully dry (check your paint label for exact cure time), mark and tape off the next shape, making sure the edge is fully sealed.

» **Helpful tip: Only fully seal the edge of the tape where the second color is going to be applied to minimize the chance of peeling the first coat of paint when you remove the tape.**

## STEP 6: Apply second color.

Use your Clearcut brush to paint corners and cut in around trim and windows. Clearcut brushes have stiff bristles to provide a sharp cut in line. Then, use an extension pole to paint larger areas with a roller.

While the paint is still damp, carefully remove the tape et voila!



Purdy